

Reflex USB Windows 98/Me

Reader Driver Install Notes

By downloading software from the SchlumbergerSema Reflex Readers Download web site, you agree to the terms and conditions of the Reader Driver License Agreement. Please read the agreement before downloading.

Package Contents

| File | Description | Version |
|--------------|-------------------|---------|
| RUSB_w9x.sys | System file | 1.16.01 |
| RUSB_w9x.inf | Setup information | |
| RUSB_w9x.cat | Security catalog | |

Installation Instructions

NOTE *The Microsoft Smart Card Base Components must be installed on the computer for the smart card reader to function properly. The Smart Card Base Components are available from the Reflex Readers Downloads website, www.reflexreaders.com/Support/Downloads/downloads.html.*

- 1 Download and extract the driver package in any available space on the computer (for example, in a \temp directory). This is a temporary location for the driver software that you will identify when you configure the Reflex USB smart card reader to use the driver.
- 2 If the Reflex USB smart card reader is not already connected to the computer, insert the Reflex USB smart card reader cable connector into an available USB port.
- 3 *If this is an initial installation*, the operating system detects the presence of the reader, and the Add New Hardware wizard is launched.
 - a When the Add New Hardware wizard window opens, click **Next**.
 - b Select **Search for the best driver for your device**, and then click **Next**.

- c** Select the **Specify a location** check box. Using standard navigation buttons and dialog boxes, specify the directory into which you extracted the downloaded driver package.
- d** When the system is ready to install the driver, click **Next**, and then to complete the operation, click **Finish**. The Add New Hardware wizard closes.
- e** Reboot the system. The Smart Card Resource Manager detects the Reflex USB smart card reader only during reboot.

If this is an update of the driver, use the Upgrade Device Driver wizard (started from the Device Manager) to configure the system to point to the new driver:

- a** To start the Device Manager, select **Start** → **Settings** → **Control Panel**. Double-click **System**, and then click the **Device Manager** tab.
- b** Expand the Smart Card Reader device type, and then double-click the name of the device to open its **Properties**.
- c** In the device's Properties, click the **Driver** tab, then click **Update Driver**. The Upgrade Device Driver wizard is launched.
- d** When the Upgrade Device Driver wizard window opens, click **Next**.
- e** Select **Search for the best driver for your device**, and then click **Next**.
- f** Select the **Specify a location** check box. Using standard navigation buttons and dialog boxes, specify the directory into which you unzipped the downloaded driver package.
- g** When the system is ready to install the driver, click **Next**, and then to complete the operation, click **Finish**. The Upgrade Device Driver wizard closes.
- h** After the wizard has finished updating the Reflex USB drivers, reboot the computer.

Additional Reader Documentation Resources

For information about installing the reader hardware and troubleshooting reader installation or operation problems, see the *Reflex USB Reader Installation Guide*, available from the Reflex Reader Technical Support website, www.reflexreaders.com/Support/support.html.

Trademarks and Copyright

Schlumberger, SchlumbergerSema, Cryptoflex, Cyberflex, Cyberflex Access, e-gate, and J-card are trademarks or registered trademarks of Schlumberger or SchlumbergerSema. Microsoft, Windows, and Windows NT are registered trademarks of Microsoft Corporation. Other company, product, and service names may be trademarks or service marks of others.

Copyright © 2002-2003 SchlumbergerSema. All rights reserved.

7 March 2003