



Auto Flash BIOS ROM SOP

The document is to describe the process of flash the BIOS ROM automatically.

1. Execute the “Win R01-B0.exe” by “Run as administrator”.



2. The system will prompt a command window and flash the BIOS ROM. After the process is done, the command window will show the string “Do you want to REBOOT?” to let user know the programming BIOS ROM is done.



3. Press “Yes”, then system will reboot.