



Enter Setup



Restore Default Settings

Interface Settings



BlueTooth Serial Port



Enable Autnehtication



PIN Code



0x03



0x00



0x03



0x00



0x03



0x00



0x03



0x00



Validate



Update