

# LT380/LT280 Quick Setup Guide

**NEC**

7N8P6232  
Printed in China  
(T)  
©NEC Display Solutions, Ltd. 2005 - 2007  
Ver. 2. 04/07

## Step 1

**Connect your computer to the projector.**


**Schließen Sie ihren Computer an den Projektor an.**

**Connecter l'ordinateur au projecteur.**

**Collegate il vostro computer al proiettore.**


**Conectar el ordenador al proyector.**

**Anslut din dator till projektorn.**




## Step 2

**1 Connect the supplied power cable.**  
**Schließen Sie das mitgelieferte Netzkabel an.**  
**Connecter le câble d'alimentation fourni.**  
**Collegate il cavo d'alimentazione in dotazione.**  
**Conecte el cable de alimentación suministrado.**  
**Anslut den medleverade nätkabeln.**




**2 Turn on the main power switch.**  
**Schalten Sie den Hauptnetzschalter ein.**  
**Enfoncer l'interrupteur d'alimentation général.**  
**Accendete l'interruttore principale.**  
**Active el interruptor de alimentación principal.**  
**Slå på huvudströmbrytaren.**



## Step 3

**Remove the lens cap.**  
**Nehmen Sie die Linsenkappe ab.**  
**Retirer le cache-objectif.**  
**Rimuovete il copriobiettivo.**  
**Quite la tapa de la lente.**  
**Ta bort linsskyddet.**



## Step 4

**Turn on the projector.**



**Schalten Sie den Projektor ein.**

**Allumer le projecteur.**

**Accensione del proiettore.**

**Encienda el proyector.**

**Slå på strömmen till projektorn.**



**Press and hold for 2 seconds**  
**Für 2 Sekunden gedrückt halten**  
**Maintenez appuyé pendant 2 secondes**  
**Premere e tenere premuto per 2 secondi**  
**Mantenga pulsado durante 2 segundos**  
**Håll intryckt i 2 sekunder**

## Step 5

**Select a source.**



**Auswählen einer Quelle.**

**Sélectionner une source.**

**Selezione di una fonte.**

**Selección de una fuente.**

**Välja en källa.**



**TIP:** Press the AUTO ADJ. button to optimize an RGB image automatically.




**TIPP:** Drücken Sie zum automatischen Optimieren des RGB-Bildes die AUTO ADJ.-Taste.

**ASTUCE:** Appuyer sur la touche AUTO ADJ. pour optimiser automatiquement une image RGB.

**SUGGERIMENTO:** Premete il tasto AUTO ADJ. per ottimizzare automaticamente l'immagine RGB.

**SUGERENCIA:** Pulse el botón de AUTO ADJ. para optimizar una imagen RGB automáticamente.

**TIPS:** Tryck på AUTO ADJ.-tangenten för att optimera en RGB-bild automatiskt.



(→ page 13, 109 of the User's Manual)

## Step 6

**Adjust the picture size and position.**

**Einstellung der Bildgröße und Bildposition.**

**Ajuster la taille et de la position de l'image.**



**Regolate delle dimensioni e della posizione dell'immagine.**

**Ajuste del tamaño y la posición de la imagen.**



**Justera bildstorlek och position.**

**Adjust the tilt foot/Einstellung des Kippfußes/  
Régler le pied de réglage de l'inclinaison/Regolate  
il piedino d'inclinazione/Ajuste de las patas de  
inclinación/Justera lutningen med foten.**

(→ Page 27 of the User's Manual)



## ZOOM



**Focus**

**Fokus**

**Mise au point optique**

**Fuoco**

**Enfoque**

**Fokus**

(→ page 28 of the User's Manual)



**Correcting Keystone Distortion [Keystone]**

**Korrigieren der Trapezverzerrung [Trapez]**

**Correction de la déformation trapézoïdale [Keystone]**

**Correzione della deformazione trapezoidale [Chiave]**

**Corrección de la distorsión trapezoidal [Keystone]**

**Korrigeren den keystone-distorsionen [Keystone]**

(→ page 29 of the User's Manual)

## Step 7

**1 Turn off the projector.**


**Schalten Sie den Projektor aus.**

**Eteignez le projecteur.**

**Spegnete il proiettore.**

**Desactive el projector.**

**Stäng av projektorn.**



**2 Turn off the Main Power switch.**


**Schalten Sie schließlich den Hauptnetzschalter aus.**

**Éteignez le commutateur d'alimentation principale.**

**Spegnete l'interruttore dell'alimentazione principale.**

**Desactive el interruptor de alimentación principal.**

**Stäng slutligen av med huvudströmbrytaren.**



**Unplug the power cable.**

**Trennen Sie das Netzkabel ab.**

**Déconnectez le câble d'alimentation.**

**Scollegate il cavo di alimentazione.**

**Desenchufe el cable de alimentación.**

**Dra ut nätkabeln.**

(→ page 33 of the user's manual)